

## INSTALLATION INSTRUCTIONS

BA6000 & BA6002 & BA6003  
BA6010 & BA6012 & BA6013

Please read carefully and save these instructions, as you may need them at a later date.

### CAUTION

**WARNING:** Risk of Fire. Consult a qualified electrician to ensure correct branch circuit conductor. Min 90°C supply conductors.

Turn off the main power at the circuit breaker before installing the fixture, in order to prevent possible shock.

### GENERAL

All electrical connections must be in accordance with local and National Electrical Code (N.E.C.) standards. If you are unfamiliar with proper electrical wiring connections obtain the services of a qualified electrician.

Remove the fixture and the mounting package from the box and make sure that no parts are missing by referencing the illustrations on the installation instructions.

### ASSEMBLY AND INSTALLATION

1. Loosen the ball nut(4) to take the socket out of the shade(1).
2. Insert the bulb(2) into the socket(3)
3. Put the bulb(2) and the socket(3) into the shade(1) and fix them with the ball nut(4)

PLEASE DON'T USE BARE FINGER TO TOUCH THE BULB.  
INSTALLATION IS NOW COMPLETE

