



by Acclaim Lighting

1500 Cherokee Parkway, Suite 100, Acworth, GA 30102
P: 866-845-5451 • F: 866-816-6165
E: service@acclaim-lighting.com • www.acclaim-lighting.com

TFA8005 & TFA9005 INSTALLATION INSTRUCTIONS

Please read carefully and save these instructions, as you may need them at a later date.

CAUTION

WARNING: Risk of Fire. Consult a qualified electrician to ensure correct branch circuit conductor. Min 90°C supply conductors.

Turn off the main power at the circuit breaker before installing the fixture, in order to prevent possible shock.

GENERAL

All electrical connections must be in accordance with local and National Electrical Code (N.E.C.) standards. If you are unfamiliar with proper electrical wiring connections obtain the services of a qualified electrician.

Remove the fixture and the mounting package from the box and make sure that no parts are missing by referencing the illustrations on the installation instructions.

ASSEMBLY AND INSTALLATION

- Carefully unpack all parts from cartons.
- Place the lamp base (D) on a flat surface.
- Thread the Screw(B) up through the Washer(C) and Marble base(D) into the Joint(E) and secure with the tool(A) until tight.
- Place the Tube(H) into the Tube(F) and fasten the Nut(G) until tight.
- Place the Tube(J) into the Tube(H) and fasten the Nut(I) until tight.
- Place the Shade(L) and the Shade(M) over the Socket(K) and secure with Ring(M) until tight.
- Install light bulb(not included) into the socket(K).

DO NOT USE BARE HANDS TO TOUCH THE BULB.

INSTALLATION IS NOW COMPLETE

